


Starfrit

ONION CHOPPER



INSTRUCTIONS FOR USE




- Chops produce in one easy motion
- Printed measurements up to 2 cups / 500 ml
- Disassembles for easy cleaning
- Non-slip feet for added stability
- Easy-pour opening to quickly and easily extract produce

TO USE

1. Clip the cleaning tool on the pusher lid before using the onion chopper.



2. Attach lid on the container. Make sure that the lid is on a flat surface before pressing down.



3. Insert the blade frame and press firmly. **Note:** Don't push directly on blade.



4. Place produce on the blade and push the lid straight down with one quick motion. Use both hands when cutting larger produce. Ease of cutting may vary depending of the firmness/size of the food. **Tip: Trim your produce for better results.**



5. To extract chopped produce, hold the pusher lid and container together so that it falls off the container's opening.



6. Use the cleaning tool to remove the residue from the pusher lid teeth after each use.



The chopping blade cuts easily through onions, potatoes, mushrooms, apples, tomatoes, bell peppers and more.

CLEANING

- Use cleaning tool to remove food residue from pusher lid.
- Handwash lid for better results.
- All other pieces are dishwasher safe.
- Assemble all pieces together to store safely.

! WARNING SHARP BLADES
Be careful when using and washing
■ this item to avoid injury.

www. **Starfrit**.com



www.facebook.com/starfrit

SUBSCRIBE TO THE NEWSLETTER TO LEARN MORE ABOUT OUR PROMOTIONS!