# Starfrit DIGITAL KITCHEN SCALE



**INSTRUCTIONS FOR USE** 

### **SPECIFICATIONS**

- Plastic weighing platform
- Also measures volume of milk and water
- Unit conversion feature
- Weight: grams, pounds and ounces
- Volume: milliliter and fluid ounces
- Automatic conversion feature imperial / metric
- Zero and tare functions Low battery and overload indicators
- Auto-off after two minutes or manual-off
- Capacity: 11 lb / 5 kg
- Accuracy: 0.1 oz / 1 g

### **BATTERY**

- Requires one 3V lithium battery (included).
- Remove isolation sheet before use.

### TO REPLACE BATTERY



- Open battery case cover on the back of the scale.
- Remove old battery by using a sharp object, as shown
- Install new battery by putting one side of the battery beneath the battery baffle and then pressing down the other side.
- Close battery case cover.

### LCD SCREEN

**WORKING MODES / UNIT CONVERSION** 

Water volume mode


**BUTTONS** 

Milk volume mode

Turn ON / Turn OFF
Zero and Tare functions

g UNITO

Press (UNIT) button to switch the mode and unit.



Mode and unit conversion

Milk volume mode

Weight mode

Weight mode Milk mode Water mode




## **WEIGHING MODE**




- weighing. Press (UNIT) button to convert
- Load weighing object on scale. LCD will show the weight reading.

### ZERO AND TARE FUNCTIONS

The zero and tare functions allow you to weigh items consecutively without having to remove the article already on the platform. For example, if you are using a bowl, these functions allow you to weigh the content of the bowl without counting the weight of the bowl. Press (b) to use these functions.



When sum of all loads on scale is less than 7 oz (200 g), the LCD will show "0 g" each time  $\left(\frac{O}{ZERO}\right)$  button is pressed. Icon "o" will show on left of LCD, indicating zero function is activated. The maximum capacity of the scale will not be reduced by the stated weight if it is 7 oz (200 g) or less.



- to reset the LCD screen at "0".


#### Zero function

### Tare function

When sum of all loads on scale is over 7 oz (200 g), the LCD will show "0 g" each time  $\frac{0}{(ZERO)}$  button is pressed. Icon "T" will show on left upper corner of LCD, indicating tare function is activated. Maximum weight capacity is reduced by tare

Under this condition, if you press  $\left(\frac{O}{ZERO}\right)$  button, you will see the total weight of all loads.

### **AUTO SHUT OFF & MANUALLY SHUT OFF**



5. DO NOT use chemical or abrasive cleaning agents. to shut off manually the scale, Press (U) button 6. Not for commercial use.

acid citrus juices.

**ADVISE FOR USE & CARE** 

1. Always use the scale on a hard flat surface.

2. Clean the scale with a slightly damp cloth.

3. Avoid contact with water, DO NOT immerse the scale in water.

4. All plastic parts should be cleaned immediately after contact with fat.

spices, vinegar and strongly flavored/colored food. Avoid contact with


#### SUBSCRIBE TO THE NEWSLETTER TO LEARN MORE ABOUT OUR PROMOTIONS LOW BATTERY & OVERLOAD INDICATORS






1. Low battery power

Please replace the battery.





Maximum capacity for this scale is 11 lb / 5 kg.

for 3 seconds and the scale will turn off.









PRINTED IN CHINA FOR: ATLANTIC PROMOTIONS INC. LONGUEUIL (QUÉBEC) J4G 1V6

# **VOLUME WEIGHING MODE**



- platform. LCD screen indicates the weight of the bowl or container. Press 💩 button
- or container, LCD screen indicates the volume of the liquid (water or milk).



- Pour liquid (water or milk) into the bowl

# Wait until LCD screen shows "0" to start weighing. Press (имит) button to convert

# to scale to water or milk mode. Place a bowl or container on the weighing